


Table of Contents

Web Application	2	Data Model	12
Features	2	ModBus TCP Data Model Implementation	14
First Login	2	EtherNet/IP™ Implementation	14
Web Application Layout	2	Rockwell Automation Integration	15
AVT Status Page	2	Automatic Diagnostic AOP Items	15
Data Logs Page	5	Troubleshooting	17
Settings Page	6	Warranty	18
Documentation Page	11	Panduit Limited Product Warranty	18
Support Page	11		

The network module is designed to be an optional accessory that enables network capabilities for the VeriSafe 2.0 Absence of Voltage Tester (AVT). The network module provides an integrated web application that is delivered by an on board web server. The web application monitors data from the AVT and provides integration, configuration and firmware update capabilities. The network module supports AVT data over EtherNet/IP and Modbus TCP protocols. The voltage presence discrete outputs may be used as an indication of voltage presence with or without a network connection. The network module provides the ability to log various pieces of data based on built in triggers (see **Data Logs Page** for more information).

Before attempting to physically install the network module in hazardous or ordinary locations, refer to document no. B21148 (VeriSafe Network Module Installation Requirements Manual) for physical installation requirements including; connectivity, ratings and environmental specifications for the network module.



TO REDUCE THE RISK OF INJURY, USER MUST READ INSTRUCTION MANUAL

NOTE: In the interest of higher quality and value, Panduit™ products are continually being improved and updated. Consequently, pictures may vary from the enclosed product.

NOTE: Updates to this Instruction Manual may be available. Check www.panduit.com for the latest version of this manual.

Tech Support

North America Tech Support:
techsupport@panduit.com
 Tel: 866.405.6654

EU Tech Support :
techsupportemea@panduit.com
 Tel: 31.546.580.452
 Fax: 31.546.580.441

Asia Pacific Tech Support:
techsupportap@panduit.com
 Tel:
 Singapore: 1-800-Panduit (7263848)
 Australia: 1-800-Panduit (7263848)
 Korea: 02.21827300

Web Application

FEATURES

The network module web application can be used to configure and monitor the AVT. Access the web application by typing the network module IP address in a supported browser.

FIRST LOGIN

1. Type the network module IP address (default: 192.168.2.10) in a supported browser.
 - Supported browsers: Chrome, Edge, Firefox
2. On first login the user is required to change the admin password

Web App Login (factory default setting)

 - Username: admin
 - Password: admin

WEB APPLICATION LAYOUT

The web application layout consists of a left sidebar menu and a content area loaded with content cards.

LOGIN
On login the user will be directed to the AVT Status page.

VeriSafe Network Module
Pump 1

AVT Status

Data Logs
Settings
Documentation
Support
Logout

Name
Pump 1
Date & Time: 9/6/22, 3:41 PM

Updated 9/5/22, 11:32 PM
Battery Voltage 3.1 V
AVT Temperature 20°C (68°F)

Updated 9/5/22, 11:32 PM
Connection Status L1 YES
Connection Status L2 YES
Connection Status L3 YES
Connection Status GND YES

Test Result 1 Pass
Test Result 1 Date 9/5/22, 11:32 PM
Test Result 2 Voltage Exceeded
Test Result 2 Date 9/5/22, 11:32 PM

Voltage Presence
L1 L2 L3
⚡ ⚡ ⚡

Voltage Measurements

Line To Ground	RMS	Peak
L1	480 Vrms	678 V
L2	479 Vrms	677 V
L3	480 Vrms	679 V

Line To Line	RMS	Peak
L1-L2	277 Vrms	392 V
L1-L3	277 Vrms	392 V
L2-L3	277 Vrms	392 V

AVT STATUS PAGE

After the user has logged in they will be redirected to the AVT Status page. This page consists of two data cards with views that will be determined by the type of AVT in use and the user settings. This page automatically refreshes content at a static rate of once every 2 seconds.

FIGURE 1. AVT STATUS PAGE 3-PHASE AVT (VS2-AVT-3P)

VeriSafe Network Module
Pump 1

AVT Status

Data Logs
Settings
Documentation
Support
Logout

Name
Pump 1
Date & Time: 9/6/22, 3:41 PM

Updated 9/5/22, 11:32 PM
Battery Voltage 3.1 V
AVT Temperature 20°C (68°F)

Updated 9/5/22, 11:32 PM
Connection Status L1 YES
Connection Status L2 YES
Connection Status L3 YES
Connection Status GND YES

Test Result 1 Pass
Test Result 1 Date 9/5/22, 11:32 PM
Test Result 2 Voltage Exceeded
Test Result 2 Date 9/5/22, 11:32 PM

Voltage Presence
L1 L2 L3
⚡ ⚡ ⚡

Voltage Measurements

Line To Ground	RMS	Peak
L1	480 Vrms	678 V
L2	479 Vrms	677 V
L3	480 Vrms	679 V


Line To Line	RMS	Peak
L1-L2	277 Vrms	392 V
L1-L3	277 Vrms	392 V
L2-L3	277 Vrms	392 V

AVT STATUS PAGE FIRST CARD

Data presented in this card is updated as described in Table 5. The user is presented with time stamps to indicate when the data was last updated. Some data will not be shown until an absence of voltage test is

completed.

FIGURE 2. AVT STATUS PAGE 1ST CARD VIEWS





1. Name	User defined AVT name (Default blank). This is used to identify data log files and appears in the side bar menu. Changes are automatically saved.
2. Date/Time	Current Date/Time of the network module. Updated every 2 seconds.
3. Battery Voltage and AVT Temperature	<p>Last measured value of the battery voltage and Internal temperature of the AVT.</p> <ul style="list-style-type: none"> Updated when the user presses the test button and during the wakeup cycle Recommended to replace battery in the AVT when measured below 2.9V.
4. Connection Status	Status of the connectivity between each pair of sensor leads based on the last completed test performed when no voltage is present.
5. Test Result 1	Show the most recent test result from the AVT
Test Result 1 Date	Date/Time of AVT test result 1
Test Result 2	Show the test result prior to test result 1
Test Result 2 Date	Date/Time of AVT test result 2
6. AC/DC Selection *(VS-AVT-1P Single phase units only)	Select appropriate power system. This will update the card view. Changes are automatically saved.

AVT STATUS PAGE SECOND CARD

Data in this card is updated every 2 seconds. For single phase systems the view shown is determined by selection on card 1 (item 6 AC/DC selection).

FIGURE 3. AVT STATUS PAGE SECOND CARD VIEWS



1. AVT Connection Status	Indicates status of the connection between the isolation module and network module.		<div><div><div>✔ OK</div><div>DISCONNECTED</div></div></div>																
2. Voltage presence 	Reflects the status of the voltage presence indicators (red LEDs) on the indicator module and voltage presence contacts on the network module.																		
3. Voltage Measurements	<div><div>■ Measured peak voltage line to ground</div><div>■ Calculated RMS and line to line voltages</div></div>	<table><tr><th>AC Range</th><th>Accuracy</th></tr><tr><td>40*-200 VAC</td><td>± 4V</td></tr><tr><td>201-300 VAC</td><td>± 2%</td></tr><tr><td>301-1000 VAC</td><td>± 1.5%</td></tr></table> <table><tr><th>DC Range</th><th>Accuracy</th></tr><tr><td>40*-300 VDC</td><td>± 9V</td></tr><tr><td>301-700 VDC</td><td>± 2%</td></tr><tr><td>701-1000 VDC</td><td>± 1.5%</td></tr></table>	AC Range	Accuracy	40*-200 VAC	± 4V	201-300 VAC	± 2%	301-1000 VAC	± 1.5%	DC Range	Accuracy	40*-300 VDC	± 9V	301-700 VDC	± 2%	701-1000 VDC	± 1.5%	<p>*The Network module is designed to report measured values between 40-1000 V. The Network module is not optimized to report voltages under 40V. However, the absence of voltage indication from the AVT utilizes a separate circuit that is highly accurate and optimized for the 3V threshold.</p>
AC Range	Accuracy																		
40*-200 VAC	± 4V																		
201-300 VAC	± 2%																		
301-1000 VAC	± 1.5%																		
DC Range	Accuracy																		
40*-300 VDC	± 9V																		
301-700 VDC	± 2%																		
701-1000 VDC	± 1.5%																		

DATA LOGS PAGE

This page allows the user to manage the log data stored on the network module SD card.

LOG TRIGGERS

Log entries are triggered by specific AVT events:

- Change in state of any voltage presence indicator
- Initiating the absence of voltage test
- Daily AVT wakeup cycle

FIGURE 4. DATA LOGS PAGE DETAILS

VeriSafe Network Module

Pump 1

AVT Status

Data Logs

Settings

Documentation

Support

Logout

Request Data Logs (1) Download Logs (CSV) (2) Download Filtered Logs (CSV) (3) Delete Logs (4)

Filters (5)

From: Start Date To: End Date

☐ L1 Voltage Not Present
☐ L2 Voltage Not Present
☐ L3 Voltage Not Present

☐ L1 Disconnected
☐ L2 Disconnected
☐ L3 Disconnected
☐ Ground Disconnected

☐ Test Initiated
☐ Test Passed
☐ Test Failed

Update Filters Clear Filters

Entry ID (6)	Date	Voltage Presence	Connection Status	Battery (V)	Last Test Result	Test Initiated	AVT Temperature	Peak Voltage L1 (V)	Peak Voltage L2 (V)	Peak Voltage L3 (V)	RMS Voltage L1 (Vrms)
21	9/6/22, 3:42 PM	L1: YES L2: NO L3: NO	L1: OK L2: OK L3: OK GND: OK	3.1	Pass	YES	20°C (68°F)	678	0	0	480
20	9/6/22, 3:41 PM	L1: YES L2: YES L3: YES	L1: OK L2: OK L3: OK GND: OK	3.1	Pass	YES	20°C (68°F)	678	677	679	480

1. Request Data Logs Request data log file from the network module
2. Download Logs (CSV) Download the data log file to local PC in CSV form
3. Download Filtered Logs (CSV) If filters are applied download the filtered data set only
4. Delete Logs Delete entries from the data log file
5. Filters Select filters. Use **Update Filters** and Clear Filters to manage selections.
6. Log Items Data associated with each log entry.

NOTE: When log data is critical it is recommended the user periodically download the logs or to integrate the system (**EtherNet/IP™** or Modbus TCP) with an external data logging system.

SETTINGS PAGE

The settings page allows the user to configure and view the current state of the network module, retrieve AVT information, check active faults, and update firmware.

FIGURE 5. SETTINGS PAGE

VeriSafe

Network Module

Pump 1

AVT Status

Data Logs

Settings

Documentation

Support

Logout

Network Module Settings

Date & Time

9/6/22, 3:44 PM

Set Time

Network Module FW Version

1.0.2rc11

Use NTP Server

☐

NTP Server Address

pool.ntp.org

Power System Configuration

Standard Wye/Delta

Modbus

☒

EtherNet/IP

☒

DHCP

☐

IP Address

192.168.2.10

Netmask

255.255.255.0

Gateway

0.0.0.0

DNS1

8.8.8.8

DNS2

8.8.4.4

Web Server Mode

Unsecure (HTTP)

Download Certificate

Select PEM Certificate

Browse...

No file selected.

Upload Certificate

Select PEM Private Key

Browse...

No file selected.

Upload Private Key

Use Custom Cert and Key

☐

Language

English

Restart

Factory Reset

Save Settings and Restart

About AVT

AVT FW Version

1.2.3

AVT Model

3039

AVT UID

40:41:42

Active Faults

ID	Description	Date & Time
----	-------------	-------------

Clear Faults

Change Password

current password

new password

confirm new password

Update Password

Password Requirements:

- Between 8 and 40 characters.
- At least 1 Special Character (!@#\$%^&*).
- At least one number.
- At least one capital letter.
- At least one lower case letter.

Passwords do not match.

Firmware Update

Select AVT Firmware

Browse...

No file selected.

Update AVT

Select Network Module Firmware

Browse...

No file selected.

Update Network Module

VeriSafe Network Module User Guide, B21176 rev 1 [English]

6

September 2022

NETWORK MODULE SETTINGS
FIGURE 6. NETWORK MODULE SETTINGS CARD DETAILS

The screenshot shows the 'Network Module Settings' card. It has a blue header with a refresh icon (1). The settings are organized into sections: 'Date & Time' (2) showing 9/6/22, 3:44 PM with a 'Set Time' button (3); 'Network Module FW Version' (4) showing 1.0.2rc11; 'Use NTP Server' (5) with a checkbox; 'NTP Server Address' (6) showing pool.ntp.org; 'Power System Configuration' (7) with a dropdown menu showing 'Standard Wye/Delta'; 'Modbus' (8) with a checked checkbox; 'EtherNet/IP' (9) with a checked checkbox; 'DHCP' (10) with an unchecked checkbox; 'IP Address' (11) showing 192.168.2.10; 'Netmask' showing 255.255.255.0; 'Gateway' (11) showing 0.0.0.0; 'DNS1' showing 8.8.8.8; 'DNS2' showing 8.8.4.4; 'Web Server Mode' (12) with a dropdown menu showing 'Unsecure (HTTP)'; 'Download Certificate' (13) button; 'Select PEM Certificate' (14) section with a 'Browse...' button and 'No file selected.' text; 'Upload Certificate' button; 'Select PEM Private Key' (15) section with a 'Browse...' button and 'No file selected.' text; 'Upload Private Key' button; 'Use Custom Cert and Key' (16) with an unchecked checkbox; 'Language' (17) dropdown menu showing 'English'; 'Restart' (18) button; 'Factory Reset' (19) button; and 'Save Settings and Restart' (20) button.

REFRESH

Replace all data in fields with the last saved settings.

SAVE SETTINGS AND RESTART

Saves modified settings and restarts the network module.

RESTART

Restart the network module without saving changes to settings.

FACTORY RESET

Reset the network module to factory default settings (see Table 4).

NOTE: If the web application is unavailable, the network module can be physically reset by depressing the User Reset Button (see Figure 1 for location on the Network Module).

1. Refresh	Replace all data in fields with the last saved settings
2. Date & Time	Displays current date and time associated with the network module.
3. Set Time	Applies local web browser time to the network module.
4. Network Module FW Version	Firmware version of the network module
5. Use NTP server	Check to enable the use of NTP (Network Time Protocol)
6. NTP server address	Enter server address to set time using NTP. Editable if Use NTP Server is checked.
7. Power System Configuration*	Configuration of the power system that the AVT is monitoring. To report accurate voltage data, the power system configuration must be selected. Default is Standard wye/delta *
8. Modbus	Enable or disable the Modbus TCP interface (default enabled)
9. EtherNet/IP™	Enable or disable the EtherNet/IP™ interface (default enabled)
10. DHCP	Enable or disable DHCP (default disabled)
11. IP Address Netmask Gateway IP DNS1 DNS2	Current IP address, Netmask and Gateway IP (read-only when DHCP is enabled) DNS1 & DNS2 are always editable
12. Web Server Mode	The web server can be configured for either HTTP or HTTPS (default is HTTP)

Continued on next page

13. Download Certificate	Download the network module certificate.
14. Upload PEM Certificate	Upload a user supplied PEM certificate (default uses on board PEM certificate)
15. Upload PEM Private Key	Upload a user supplied PEM private key (default uses on board PEM private key)
16. Use Custom Cert and Key	Check to enable use of the user supplied certificate and private key for HTTPS. Disabled if HTTPS is not selected for Web Server Mode.
17. Language	Select desired language from the drop-down menu. English, French, French (Canada), German, Italian, Korean, Spanish (Latin America), Chinese
18. Restart	Restart the network module without saving changes to settings
19. Factory Reset	Reset the network module to factory default settings
20. Save Settings and Restart	Saves modified settings and restarts the network module.

***POWER SYSTEM CONFIGURATION**

The AVT measures voltage between the sensor leads and ground leads and computes the associated phase-to-phase and RMS voltages reported by the network module. To report accurate voltage data, the power system configuration must be selected. The Standard selection (default) assumes a wye or delta power system and is sufficient for most applications. If a special configuration (corner grounded delta, high-leg delta, and single-phase 3-wire) is desired, select the appropriate application from the drop-down menu.

ABOUT AVT

Displays firmware version, model number and universal identifier (UID) of the AVT. Use the refresh button to update the card.

About AVT

AVT FW Version1.2.3

AVT Model3039

AVT UID40:41:42

Refresh

AVT Data

ACTIVE FAULTS

This card will display active faults in the network module. The fault information is updated automatically every 3 seconds. See Troubleshooting for additional information.

Active Faults

IDDescriptionDate & Time

4Timeout while communicating with AVT9/6/22, 3:47 PM

Clear Faults

21. Faults


ID	Description
0	Hardware Failure. Flash code 2 during boot up
1	Power from the network module to the AVT is over the limit.
2	Indicate the network module has been reset to factory defaults
3	Data received from AVT was unable to be processed
4	Timeout while communicating with AVT
5	General SD card error
6	SD card is full
7	Time has not updated
8	Time not set
9	Web server could not load custom certificate

22. Clear Faults

The Clear Faults button allows the user to clear any faults on the network module. If the fault condition is still present the fault may be presented after some time.

CHANGE PASSWORD

On initial login and factory reset the user will be prompted to change the password.




The 'Change Password' form contains three input fields: 'current password', 'new password', and 'confirm new password'. Below the 'new password' field, there are red 'Password Requirements' listed as bullet points: 'Between 8 and 40 characters', 'At least 1 Special Character (!@#\$%^&*)', 'At least one number', 'At least one capital letter', and 'At least one lower case letter'. Below the 'confirm new password' field, a red error message states 'Passwords do not match.' A grey 'Update Password' button is located at the bottom right of the form.

UPDATE FIRMWARE

Download the latest firmware at www.panduit.com

Select **Choose File**, navigate to the firmware file, and click the appropriate **Update** button.. The firmware update process for both the network module and AVT should take approximately one minute.



The 'Firmware Update' form is divided into two sections. The first section, 'Select AVT Firmware', includes a 'Browse...' button, the text 'No file selected.', and an 'Update AVT' button with a yellow '1' icon. The second section, 'Select Network Module Firmware', includes a 'Browse...' button, the text 'No file selected.', and an 'Update Network Module' button with a yellow '2' icon.

AVT Firmware Update

During a firmware update communication between the network module and the AVT will be temporarily lost. Upon successful update use the **About AVT** card refresh button to verify the firmware version matches what was downloaded.




Network Module Firmware Update

Upon successful firmware update the network module will restart and you will be prompted to login.

DOCUMENTATION PAGE

This page provides the user with the information necessary to utilize the **EtherNet/IP™** (EDS file download) and Modbus TCP communications protocols.

FIGURE 7. DOCUMENTATION PAGE

**VeriSafe™**
Network Module

Pump 1

AVT Status

Data Logs

Settings

Documentation

Support

Logout

Data Model

Data Item	Description	Data Type
Date Time	Current date and time set in the gateway. Microseconds since epoch.	UINT64
Battery Voltage	Last voltage reading of the AVT battery	FLOAT
Voltage Presence	Voltage Presence. Bits L3:L2:L1	UINT16
Connectivity Status	Connected Status of each sensor lead L1, L2, L3, PE Ground during last test.	UINT16
RMS Line Voltage L1 - G	RMS Voltage from L1 to Ground	UINT16
RMS Line Voltage L2 - G	RMS Voltage from L2 to Ground	UINT16
RMS Line Voltage L3 - G	RMS Voltage from L3 to Ground	UINT16
RMS Line Voltage L1 - L2	RMS Voltage from L1 to L2	UINT16
RMS Line Voltage L1 - L3	RMS Voltage from L1 to L3	UINT16
RMS Line Voltage L2 - L3	RMS Voltage from L2 to L3	UINT16
Peak Line Voltage L1 - G	Peak Voltage from L1 to Ground	UINT16
Peak Line Voltage L2 - G	Peak Voltage from L2 to Ground	UINT16
Peak Line Voltage L3 - G	Peak Voltage from L3 to Ground	UINT16
Peak Line Voltage L1 - L2	Peak Voltage from L1 to L2	UINT16
Peak Line Voltage L1 - L3	Peak Voltage from L1 to L3	UINT16
Peak Line Voltage L2 - L3	Peak Voltage from L2 to L3	UINT16
AVT Temperature	Temperature inside the AVT	UINT16
Disconnect State (Unused)	UNUSED	UINT16
Status	Status bits associated with the network module and AVT.	UINT32
AVT Result 1	Most recent Test Result of an AVT test.	UINT16
AVT Result 2	Second Most recent Test Result of an AVT test.	UINT16
AVT Result 1 Datetime	Datetime of AVT Result 1. Microseconds since epoch.	UINT64
AVT Result 2 Datetime	Datetime of AVT Result 2. Microseconds since epoch.	UINT64

EtherNet/IP


[Download EDS File](#)

Modbus TCP Data Model Implementation

SUPPORT PAGE

- Provides contact information and a link to the VeriSafe landing page on www.panduit.com
- Queries the AVT and network module for product information to assist in technical support.

FIGURE 8. SUPPORT PAGE

**VeriSafe™**
Network Module

Pump 1

AVT Status

Data Logs

Settings

Documentation

Support

Logout

Network Module Firmware Update

Upon successful firmware update the network module will restart and you will be prompted to login.

Support Information

[Verisafe Support Page](#)

Support Email Address

US/CAN/LATAM
EMEA
APAC

techsupport@panduit.com
techsupportemea@panduit.com
TechSupportAP@panduit.com

Support Phone Number

English
UK
Singapore/AUS
Français
Français (Canada)
Italiano
한국어
Deutsch
Español (América Latina)
中文 (简体)

1-866-405-6654
+31-546-580-452
1-800-Panduit (7263848)
+31-546-580-452
1-866-405-6654
+31-546-580-452
02-21827300
+31-546-580-452
1-866-405-6654
+86-400-820-1900

Network Module FW Version	1.0.2rc11
AVT FW Version	1.2.3
AVT Model	3039
AVT UID	40:41:42

Data Model

The network module uses the same data model for both **EtherNet/IP™** and Modbus TCP protocols.

Item Name		Description		Value Type (size bytes)	Range	
Date/Time		Current Date/Time set in the network module		LINT(8)	microseconds since epoch	
Battery voltage		Last voltage reading of the AVT battery (last test)		REAL(4)	0.0 to 4.0 V	
Voltage presence		Bit field status of the phase indicator LEDs (red LEDs)		WORD(2)	Bit	Bit Name
					0	Present L1 POS
					1	Present L2 NEG
					2	Present L3
					0: Voltage not detected 1: Voltage detected	
Connectivity status		Connected status of each sensor lead L1, L2, L3, PE Ground during last test.		WORD(2)	Bit	Bit Name
					0	Connected L1
					1	Connected L2
					2	Connected L3
					3	Connected PE GND
0: Sensor lead disconnected 1: Sensor lead connected						
Line voltage	L1-G	RMS voltage	L1 to Ground	INT(2)	0 to 1100 Vrms	
	L2-G		L2 to Ground			
	L3-G		L3 to Ground			
	L1-L2		L1 to L2			
	L1-L3		L1 to L3			
	L2-L3		L2 to L3			
Peak line voltage	L1-G	Peak voltage	L1 to Ground		0 to 1500 V	
	L2-G		L2 to Ground			
	L3-G		L3 to Ground			
	L1-L2		L1 to L2			
	L1-L3		L1 to L3			
	L2-L3		L2 to L3			
AVT temperature		Temperature inside the isolation module		-40°C to 85°C (-40°F to 185°F)		
Disconnect state [NOT IMPLEMENTED]		Disconnect phase open or closed		WORD(2)	Bit	Description
					0	L1 open
					1	L2 open
					2	L3 open
					0: Blade closed 1: Blade open	

Continued on next page

Status bits associated with the network module and AVT

	DWORD(4) Bit							
	0	1	2	3	4	5	6	7
	Battery Warning Indicator	AVT Temperature Fault	AVT Power Source	Phase Number	User Threshold Triggered	Disconnect Module Present	AVT Internal Fault	Network Module Fault
Status	0: Battery OK	0: OK	0: Battery	0: 3 Phase	[NOT IMPLEMENTED]	[NOT IMPLEMENTED]	0: OK	0: OK
	1: Check battery (low or not present)	1: Fault	1: Aux	1: Single phase	0: Not triggered 1: Triggered If any user defined threshold is triggered this bit will go to active (1)	0: No 1: Yes	1: Fault	1: Fault

Item Name	Description	Value Type (size bytes)	Range
AVT result 1 Date/Time	Date/Time of AVT result 1	LINT(8)	microseconds since epoch UTC

- Most recent test result of an AVT test
- This report has the following possible bit states to indicate a passed test or the reason for a failed AVT test

	DWORD(2) Bit							
	0	1	2	3	4	5	6	7
	Passed	Battery Voltage Low	Voltage Exceeded	Temperature not in Range	Connectivity not Confirmed	Diagnostic 5	Diagnostic 6	Diagnostic 7
AVT Result 1	0F	1F	2F	3F	4F	5F	6F	7F
								8

#F indicates the number of flashes that will be seen on the AVT indicator module for this error code

0: false
1: true

AVT result 2 Date/Time	Date/Time of AVT result 2	LINT(8)	microseconds since epoch UTC
------------------------	---------------------------	---------	------------------------------

- Second most recent test result of an AVT test
- This report has the following possible bit states to indicate a passed test or the reason for a failed AVT test

	DWORD(2) Bit							
	0	1	2	3	4	5	6	7
	Passed	Battery Voltage Low	Voltage Exceeded	Temperature not in Range	Connectivity not Confirmed	Diagnostic 5	Diagnostic 6	Diagnostic 7
AVT Result 2	0F	1F	2F	3F	4F	5F	6F	7F
								8

#F indicates the number of flashes that will be seen on the AVT indicator module for this error code

0: false
1: true

MODBUS TCP DATA MODEL IMPLEMENTATION

All values are contained in input registers (offset 30000).

Data Item		Start Address	Size (16bit words)	End Address
Date/Time		0	4 (uint64)	3
Battery voltage		4	2 (float)	5
Voltage presence		6	1 (uint16)	6
Connectivity status		7		7
Line voltage	L1-G	8	1 (int16)	8
	L2-G	9		9
	L3-G	10		10
Line voltage peak	L1	11		11
	L2	12		12
	L3	13		13
Line voltage	L1-L2	14		14
	L1-L3	15		15
	L2-L3	16		16
Line voltage peak	L1-L2	17		17
	L1-L3	18		18
	L2-L3	19		19
Temperature		20	1 (int16)	20
Disconnect state		21	1 (uint16)	21
Status		22	2 (uint32)	23
AVT result 1		24	1 (uint16)	24
AVT result 2		25		25
AVT result 1 Date/Time		26	4 (uint64)	29
AVT result 2 Date/Time		30		33

EtherNet/IP™ IMPLEMENTATION

The network module supports **EtherNet/IP™**. The EDS file can be found on the documentation page of the web application or by going to panduit.com.

Rockwell Automation Integration

The **EtherNet/IP™** protocol is supplemented by a Add-On Profile (AOP) for easy integration with products from Rockwell Automation. The AOP supports the Automatic Diagnostics feature.

- AOP available in Studio 5000 Logix Designer V33.01 or greater

AUTOMATIC DIAGNOSTIC AOP ITEMS

REQUIREMENTS

- Logix controller must be V33 or greater
- Factory Talk View software must be V12 or greater

CONNECTIVITY STATUS

WORD(2)

- Sensor lead status is based on the last completed test. This value will only be updated when a test is completed with no voltage present.

TABLE 1.

	Bit			
	0	1	2	3
Connectivity Status	Connected L1	Connected L2	Connected L3	Connected PE GND
Diagnostic Message	0: L1 Sensor lead disconnected	0: L2 Sensor lead disconnected	0: L3 Sensor lead disconnected	0: PE GND Sensor lead disconnected
	1: L1 Sensor lead connected	1: L2 Sensor lead connected	1: L3 Sensor lead connected	1: PE GND Sensor lead connected

STATUS

DWORD(4)

- Status bits associated with the network module and AVT. This value will only be updated when an absence of voltage test is completed.

TABLE 2.

	Bit			
	0	1	2	3
Status	Battery Warning Indicator	AVT Temperature Fault	AVT Internal Fault	Network Module Fault
	0: Battery OK	0: OK	0: OK	0: OK
	1: Check battery (Battery low or not present)	1: Fault	1: Fault	1: Fault
Diagnostic Message	0: Battery OK	0: AVT temperature OK	0: AVT OK	0: Network module OK
	1: Check battery	1: AVT temperature fault	1: AVT Internal fault	1: Network module fault

AVT RESULT 1

WORD(2)

- Most recent test result of an AVT test
 - This report has the following possible bit states to indicate a passed test or the reason for a failed AVT test

TABLE 3.

	Bit				
	0	1	2	3	4
AVT Result 1	Passed 0F	Battery voltage low 1F	Voltage exceeded 2F	Temperature not in range 3F	Connectivity not confirmed 4F
Diagnostic Message	0: AVT test failed 1: AVT test passed	0: OK 1: AVT battery low	0: OK 1: Voltage exceeds AVT limits	0: OK 1: AVT temperature outside supported range	0: OK 1: AVT sensor lead disconnected

	Bit continued			
	5	6	7	8
AVT Result 1	Diagnostic 5 5F	Diagnostic 6 6F	Diagnostic 7 7F	Diagnostic 8
Diagnostic Message	0: OK 1: AVT diagnostic 5	0: OK 1: AVT diagnostic 6	0: OK 1: AVT diagnostic 7	0: OK 1: AVT diagnostic 8

Troubleshooting

FAULTS

When a fault is active the user will also see an exclamation point in the left sidebar and in the active faults menu of the settings page

Fault	Troubleshooting
Hardware Failure (0) Network module system status indicator 2 flash error code	Contact Panduit support
Power over limit (1)	Check AVT connection for proper termination.
Settings files reset to factory defaults(2)	Expected if new unit or user initiated a factory reset, do nothing in this case If repeatedly occurs replace unit
Data received from AVT was unable to be processed (3) Timeout while communicating with AVT (4)	Check AVT connection Check AVT and Network module termination resistor switch positions. Move AVT connection cable away from possible noise sources
SD card error (5)	Contact Panduit for support around SD Card errors and possibly reseating or replacing the SD Card.
SD card full (6)	download logs (if necessary) and then delete logs from the web interface. restart the unit and confirm the system is able to log.
Stale Time (7)	Check NTP server can be reached from device location
Time not set (8)	Set time using the settings page (set time button or NTP time setup)
Could not load custom certificate(9)	Check that the certificate was generated properly and upload again.

CLEARING FAULTS

The user has the ability to clear active faults (see **Faults** section). If the network module determines the fault is still active it will repopulate. To verify a fault has been cleared restart the network module.

Warranty

PANDUIT LIMITED PRODUCT WARRANTY

1. **Limited Product Warranty.** For purposes of this Limited Product Warranty, “Panduit products” mean all Panduit-branded products that Panduit sells. Unless a different time period is set forth in the Panduit product manual, user guide or other product documentation, Panduit warrants that the Panduit product, and each part or component of the Panduit product, will comply with Panduit’s published specifications and will be free from defects in material and workmanship for a period of 1 year from the date of invoice from Panduit or its authorized distributor, not to exceed 18 months from the original date of shipment from Panduit’s facility.
2. **Firmware.** Unless otherwise provided in a separate license agreement, and subject to the limitations for third-party products set forth below, Panduit warrants that any firmware contained in any Panduit products, when used with Panduit-specified hardware and when installed properly, will perform in accordance with the Panduit published specifications for a period of 1 year from the date of invoice from Panduit or its authorized distributor, not to exceed 18 months from the original date of shipment from Panduit’s facility. Any exceptions to this 1 year warranty period will be identified in the Panduit product manual, user guide or other product documentation. Panduit does not warrant that the operation of the firmware will be uninterrupted or error-free, or that the functions contained therein will meet or satisfy Buyer’s intended use or requirements. Any warranties, if any, that Panduit provides for any standalone software that Panduit sells will be stated in the applicable End User License Agreement.
3. **Remedies.** Panduit’s sole and exclusive obligation and Buyer’s exclusive remedy under this warranty is Panduit’s repair or replacement of the defective Panduit product. Panduit shall have sole discretion as to which of these remedies Panduit will provide to Buyer. Buyer requested on-site warranty service is not covered and will be at Buyer’s sole expense, unless authorized in writing by Panduit in advance of the commencement of the on-site warranty service. Panduit has the right to either examine the Panduit products where they are located or, in its sole discretion, issue shipping instructions for return of the product. Where applicable, Buyer must return the defective product, part or component, transportation prepaid to Panduit’s customer service department accompanied by Panduit’s Return Material Authorization. If Panduit confirms that there is a defect that is covered by this warranty, the repaired or replaced Panduit product will be warranted for the remainder of the warranty period applicable to the originally shipped Panduit product, or for a period of 90 days from the date of shipment to Buyer, whichever is longer.
4. **No Warranty for Third-Party Products.** Panduit makes no representations and disclaims all warranties of any kind, express or implied relative to any third-party product or services, including any third-party software or firmware, which may be incorporated into a Panduit product and/or resold or sublicensed by Panduit. To the extent any warranties extended to Panduit by the third-party manufacturer are transferable, Panduit will transfer such warranties to Buyer and any enforcement of such third-party warranties shall be between the Buyer and the third-party. Panduit does not warrant the compatibility of the Panduit products with the products of other manufacturers or Buyer’s application except to the extent expressly represented in Panduit’s published specifications or written quotation.
5. **Exclusions.** Before using, Buyer shall determine the suitability of the Panduit product for his intended use and Buyer assumes all risk and liability whatsoever in connection therewith. The warranties contained herein shall not apply to any Panduit products that have been subjected to misuse, neglect, improper storage, handling, installation or accidental damage or modified or altered by persons other than Panduit or persons authorized by Panduit. In addition, the firmware warranty does not cover any defects resulting from Buyer-supplied firmware or unauthorized interfacing, operation outside of the environmental specifications for the products, or improper or inadequate site preparation or maintenance by Buyer. Panduit products are not designed, intended or authorized to be used in medical applications or as components in medical devices that are used to sustain or support human life. Should Buyer purchase or use a Panduit product for any such unintended or unauthorized medical application, Buyer shall indemnify and hold Panduit harmless from any liability or damage whatsoever arising out of the use of Panduit products in such medical applications.
6. **LIMITATION ON LIABILITY. THE WARRANTIES PROVIDED HEREIN ARE BUYER’S SOLE AND EXCLUSIVE WARRANTIES. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR USE ARE DISCLAIMED. TO THE EXTENT PERMITTED BY LAW, IN NO EVENT SHALL PANDUIT BE LIABLE FOR ANY LOSS OR DAMAGES ARISING FROM ANY PANDUIT PRODUCT WHETHER DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL OR SPECIAL, INCLUDING WITHOUT LIMITATION ANY CLAIM FOR LOSS OF DATA, LOSS OF ACTUAL OR ANTICIPATED REVENUE, PROFITS OR SAVINGS.**
7. **General.** This Limited Product Warranty applies to the Panduit products only and not to any combination or assembly of the Panduit products. Nothing in this Limited Product Warranty shall be construed to provide Buyer with a warranty for any system implementation using Panduit products. The Panduit Certification Plus System Warranty is available for projects that are installed by Panduit Certified Installers, meet various requirements and are registered with Panduit in accordance with the terms of the Panduit Certification Plus System Warranty.

