

# MP75 PRINTER

Quick Reference Card



Printer Tech Support 1-866-871-4571  
GA-TECHSUPPORT@PANDUIT.COM  
Rev. 0.0 – 2/12/2021



## MP75 Printer and Accessories

Part No.	Description
MP75	Includes MP75 printer and 1 cassette of T075X000VPM-BK.

## MP75 Label Cassettes


- Continuous label materials:
  - Heat Shrink Tubing
  - Nylon Cloth Tape
  - Polyolefin Tape
  - Colored Vinyl Tape
  - Clear Polyester Tape
- Compatible for use with Panduit MP Cassette Continuous Label Material up to 3/4" wide

## Label Cassette Types

Label Material	Example Part No.	Typical Application
Heat Shrink Tubing	H000X025H1M	Wire/Cable Marking
Nylon Cloth Tape	T050X000C1M-BK	Wire/Cable Marking
Polyolefin Tape	T038X000FJM-BK	Terminal Block Labeling
Colored Vinyl Tape	T075X000VPM-BK	Safety/Facility and General Identification
Clear Polyester Tape	T075X000YKM-BK	Safety/Facility and General Identification

## Getting Started

- Included Items



MP75 Printer    Label Cassette    Documents

## Compliance Markings




## Printer Setup


### Install Batteries

**CAUTION**  
Always use AA-size alkaline batteries.

1. Open the battery cover/cassette door on the back of the printer.




2. Insert 6 AA alkaline batteries. Do Not Reverse Polarity.




### Insert a label cassette into the printer


1. Remove any slack in the tape inside the cassette (if needed).




2. Open the battery cover/cassette door and place the cassette into the printer as shown.



3. Close the cassette door/printer cover.




### MP75 Keypad Functions:



1. Power On/Off  
⏻ + ⏻ : To "Print Density" Menu (When the power is off)
2. Change Font
3. Change Font Size
4. Add/Remove Frame
5. Change Font Style
6. Text Options Key
7. Number and Letter Keys
8. Shift/Secondary Functions
9. CAPS Lock
10. Enter Character with an Accent
11. Space Bar
12. Shift/Secondary Functions
13. Enter Key
14. Primary Punctuation Marks/Secondary Punctuation Marks
15. Delete/Clear Key
16. Create a Symbol/Create Serialization
17. Select Label Mode/Create Barcode
18. Create Copies
19. Preview Key/Display Setup Menu
20. Directional Pad/File Save and Recall
21. Print a Label/Feed Label Material
22. Cut Button
23. Display Screen

MP75 Display




- 1. Font Size
- 2. Font Width
- 3. Frame
- 4. Font Style
- 5. Vertical Text
- 6. Battery Life
- 7. Accent Mark Indicator
- 8. Lower Case / Upper Case Indicator (CAPS lock)
- 9. Cursor
- 10. Line Number
- 11. Page Number

9


Label Mode

LABEL MODE

1. Tab – Medium




2. Tab – Small




3. Tab – Large



4. Flag – Horizontal




5. Flag – Vertical




6. Flag – Edge



7. Wrap




8. Ribbon




10

HOW TO: Serialization

1. Type "A-"
2. Press the SHIFT and SYMBOL key
3. Enter a start value of '1'
4. Press the ENTER key
5. Press the PRINT key
6. Once printing is completed, press the Cut Button on the right side of the printer to cut the first label.
7. The number/letter automatically increases by one once printing is done. Continue to press PRINT until all needed labels are printed.



1. Type "A - "
2. Press the SHIFT and SYMBOL key
3. Enter a start value of '1'
4. Press the ENTER key
5. Press COPIES
6. Press ENTER on Copies
7. Enter a value of '3' for copies
8. Press ENTER, the labels with sequenced numbers will begin printing
9. Once printing is completed, press the Cut button on the side of the printer
10. Manually cut each label



11

HOW TO: Symbols



1. Press the SYMBOL key
2. Select the symbol group named Safety by using the up and down arrows on the directional pad
3. Select the symbol by scrolling to the right using the directional pad
4. Press ENTER
5. Press SPACE
6. Type "CAUTION"
7. Press PRINT
8. Press the Cut Button on the right side of the printer

Example using T075X000VXM-BK, black on yellow continuous vinyl tape:



Over 20 categories of symbols available.  
Hundreds of individual images are included.



12

HOW TO: Barcodes

Code 39

1. Access the Barcode Function by pressing the SHIFT and LABEL MODE button at the same time
2. Scroll to CODE 39 and press ENTER
3. Select Medium Width
4. Select 2.5 Ratio
5. Select check digit OFF
6. Type text ABC
7. Press PRINT
8. Use Manual Cutter Button on Right side of Printer to cut label



13

Display Setup

To Access the Printer Display Settings, Press the SHIFT and PREVIEW key

- Backlight – Turn backlight function ON or OFF
- Contrast – Adjust the contrast for the printer screen
- Language – Select the preferred language. 8 languages are available: English, Español, Français, Português – BR, Português – EU, Italiano, Nederlands, Deutsch
- Inch:cm – Change the unit of measure between inches and centimeters

Other Functions

- PRINT – Print labels
- COPIES – Set cut mode and choose number of copies to print
- FEED – Feeds label material without printing
- CLEAR – Clear screen, remove formatting
- FILE – Save or recall label files
- FONT – Change the font for the text
- FONT SIZE – Change the character size
- TEXT OPTIONS – Change the font styling
- PREVIEW – View the contents of the label before printing
- FRAME – Add or remove a frame around the text of the label

14

Additional Support

Visit [www.panduit.com](http://www.panduit.com)

Free Downloads

Path: Support / Download Center / Software  
Firmware Printers

- Replacement Quick Reference Card
- Product Bulletin
- Product specification and safety information.

Warranty Registration

Path: Support / Product Registration

Related Products

- MP Label Cassettes
- MP100 Printer
- MP200 Printer
- MP300 Printer

Note: Please refer to the instruction label in cassette compartment for the printer head cleaning.

15

Global Customer Service

- CS@PANDUIT.COM
- U.S. and Canada: 800-777-3300
- Europe, Middle East, and Africa: 44.20.8601.7200
- Latin America: 52.33.3777.6000
- Asia Pacific: 65.6305.7575

Panduit Technical Support

- [GA-TECHSUPPORT@PANDUIT.COM](mailto:GA-TECHSUPPORT@PANDUIT.COM)
- U.S. and Canada: 1-866-871-4571
- Europe: 31.546.580.452
- Latin America: 52.33.3777.6000
- Asia Pacific: 65.6379.6700

Part Number: MP75-QRC-EN, Rev. 0.0  
DWG Number: 00817EBA

16