

WORK INSTRUCTION


Using SmartZone Reports				
Applies to:	SmartZone Users			
Objective:	Select, view, print, and export SmartZone DCIM Reports.			
Documentation Reference:	SmartZone User Manual – SmartZone Reports – Using Reports			
Pre-Requisites:	SmartZone Reports installed and configured on a (preferably) separate server.			


Description

This procedure allows you to select, view, print, and export SmartZone DCIM Reports.

Performing the Procedure

Step	Instruction	Graphic	Result
1	In SmartZone, click the Reports module tab.	ASSET CONNECT POWER ENVIRO COMMON Asset Profile Port Usage Power Capacity Power Usage Environmental Performance Power Ranking Power Chan New York Cut Rack test (6 Power Ranking Power Chan New York Cut Rack test (6 Power Profile Power Chan New York Cut Rack test (6 Power Profile Power Chan New York Cut Rack test (6 Power Profile Power Chan New York Cott Rack test (6 Power Profile Power Chan New York LPS Capacity LPS Usage Cost Analysis Executive Summary	The list of all SmartZone reports displays.
2	Select a report.	Carried Medicities	The report displays.





Step	Instruction	Graphic		Result
9	If the MS Excel spreadsheet image doesn't display in a separate tab in your browser, click press here.	Excel Export The requested content has been opened in another window. If you know that this is not the case, press here	QlikView	The spreadsheet file icon displays at the bottom of your browser. Click it and select the download
		ОК		option.
	End of Steps			

End State

The report has been built, filtered, printed, and exported to MS Excel.