© Panduit Corp. 2024   **INSTALLATION INSTRUCTIONS**   **V00030AE_07**

PART NUMBERS

Table 1

| VERTICAL CABLE MANAGEMENT		Mounting Kits (sold separately)	Racks
Front/Rear	**Front Only**	WMPVCBE (Center Mount) (Standard mounting for Panduit 2 and 4 post racks racks. One kit Included.)	R2P Series of Racks R4P Series of Racks
WMPV22E	WMPVF22E		
WMPV45E	WMPVF45E		
WMPVHC45E	WMPVHCF45E		

Location Guide for Center Mounting
(**R2P** with **WMPVCBE**)
Dimensions in ( ) parenthesis are for 6" Vertical Cable Management



Bracket Installation   ①

Note:
For additional brackets when installing between two racks use part number **WMPVCBE**. Bracket is keyed to be installed in the correct orientation.

Standard Rack Installation

②

Note:
Arrows and flags must point upward

④

Rear Bottom Mounting Location

#12-24 Screws

#12-24 Screws

③

Bottom Mounting Location

**Location pin(s)**

Top Mounting Location

Installation Instructions R2PS using WMPVSMK side mounting kit
Note: Mount the racks to the floor (with the appropriate space between racks indicated in Table 2.)

Table 2

Part Number	Space
WMPV22E	
WMPV45E	
WMPVF22E *	5"
WMPVF45E *	
WMPVHC45E	6.75"
WMPVHCF45E *	

* FOR USE WITH R2P6S

Location pin(s)

3/8 Bolt, Lock Washer & Nut

3/8 Bolt, Lock Washer & Nut

Installation Instructions Required mounting for R2P6S using WMPVSMK side mounting kit
**Note**: Mount the racks to the floor (with the appropriate space between racks indicated in Table 2.)

3/8 Bolt, Lock Washer & Nut

Location pin(s)

3/8 Bolt, Lock Washer & Nut

Installing Front Only Managers for Front and Back cable management.
Use a front only manager for additional cable management on the back of the rack (see Table 2 for all compatible managers for this rack)


Front Only Manager

Front Only Manager

Installation Instructions R4P using WMPVSMK side mounting kit

Note: Mount the racks to the floor (with the appropriate space between racks indicated in Table 2.)

① ③

3/8 Bolt, Lock Washer & Nut

Location pin(s)

②

3/8 Bolt, Lock Washer & Nut

Opening and Closing Cover for WMPV managers

Opening   **Open**   **Closing**   **Removal**

Wire Retainer Installation (WR5E) SOLD SEPERATELY

Use thumb to release wire retainer for removal